

GETTING STARTED

KIOSK

You will receive your Consumer Drug Take-Back kiosk and your supplies in separate shipments. After unpacking the Consumer Drug Take-Back kiosk, it must be installed according to the “Responsible Disposal Act” Rule which means it must be connected to a wall or the floor ensuring the kiosk is secure. Your kiosk will come pre-drilled in the bottom to make installation easier. Please see the installation instructions included in this email.

Your usage of the Inmar Consumer Drug Take-Back Program indicates your agreement to accept responsibility for following the Federal Guidelines. DEA’s Final Rule, which implements the Secure and Responsible Drug Disposal Act of 2010 (“the Disposal Act”).

SUPPLIES

After completing the proper installation of your Consumer Drug Take-Back kiosk, you should unpack your supplies.

Included are supplies to operate your Consumer Drug Take-Back program for 3 shipments. Upon Inmar’s receipt of your second container (return) shipment, we will automatically send your next 3 shipment supply package so you will always have the necessary supplies on hand. Staged shipping of your supplies alleviates your need to store large supply quantities.

Each shipment contains 3 individually-packaged kits with unique components to each kit. DO NOT rearrange contents between kits.


Each kit contains one of each of the following:

- Serialized Inner Liner
- Absorption pad
- Serialization Tracking Sheet (emailed separately)
- Black Zip Tie
- Set of instructions (Single Page)
- Numbered and pre-labeled cardboard box

It is important for you to document receipt of the serialized Inner Liners on your tracking form. To assist, Inmar has provided the Serialization Tracking sheet (Inner Liner Tracking Form). Maintain a copy of the completed Serialization Tracking Sheet in your files for at least 2 years (at the collector’s registered location). Refer to 21 CFR § 1304.04(a).

CONSTRUCTING YOUR INNER CONTAINER

Construct 1 cardboard container applying an appropriate amount of tape to the bottom to ensure safe transportation. Seal the middle seam and both outside seams. Leave no untaped spaces along the seams and no less than 3 inches of tape overhang on each side. We recommend 2 strips of tape across the bottom seam and 2 strips of tape over the edge seams and 2 strips of tape across the bottom of the container placed diagonally. See illustration to right.



NOTE: All direct contact with the unsealed Consumer Drug Take-Back liner must be performed by two pharmacy personnel.

PREPARING YOUR CONTAINER FOR USAGE

1. Place Serialized Inner Liner into the box and fold excess material at top over box flaps. Leave Black Zip Tie taped to the Liner for later use. (When inserting Inner Liner, check to ensure Serial Number on Serialized Inner Liner matches Serial Number on the shipping container.)
2. Place absorbent pad into the installed Liner.
3. Install the lined box (now the "Container") into the Collection Kiosk.
4. Immediately document installation of Container (column 3 of the Serialization Tracking Sheet).

5. Store remaining spare kits securely for future use.
6. Lock bottom door and unlock top door to begin CDTB collection.

NOTE: All direct contact with the unsealed Consumer Drug Take-Back liner must be performed by two pharmacy personnel.

PREPARING YOUR CONTAINER FOR SHIPPING

Note: The total weight of the Container ready for shipping MAY NOT EXCEED 66 POUNDS IN WEIGHT.

1. Unlock and open bottom door.
2. Remove full Container from Collection Kiosk.
DO NOT sort, count or inventory pharmaceuticals or touch contents of Liner prior to sealing.
3. Immediately seal the Serialized Inner Liner by gathering the top of the Liner, bending the gathered portion at the halfway point and folding the top half alongside the bottom half. For extra security, bend the gathered portion at the halfway point a 2nd time. While folding Liner, keep Serial Number on Liner visible. Securely cinch the provided Black Zip Tie around both halves of the gathered portion of the Liner to secure the top. Ensure that the zip tie is completely above the exposed end of the top half of

the gathered portion and that the zip tie is fully tightened. This will provide an airtight seal at the open end of the Liner to prevent leakage of any trace liquids that may be inside. See next page for illustration.

4. Close and tape the box top. Seal the middle seam and both outside seams. Leave no untaped spaces along the seams and no less than 3 inches of tape overhang on each side. We recommend 2 strips of tape across the top seam and 2 strips of tape over the edge seams and 2 strips of tape across the top of the container placed diagonally. See illustration of taping method above.
5. Document removal of Container (in column 4 of Serialization Tracking Sheet).
6. Store the sealed Container in a secure location until shipped.

SHIPPING AND RECORD KEEPING

Note: Container is pre-labeled and ready to return. The marking requirements of 49 CFR 172.301(c) do not apply. The container shall not contain any markings to indicate that the contents contain controlled substances.

1. Ship in accordance with the DOT Special Permit.
Container comes pre-paid and pre-labeled for shipping.
2. When the Liner is shipped, complete column 5 on the Serialization Tracking Sheet. The completed Serialization Tracking Sheet is a record of Liner Events and should be filed in accordance with DEA guidelines. Schedule a pickup on FedEx.com by clicking "Shipping" then from the drop-down menu selecting "Schedule & Manage Pickups."

Click "Schedule a pickup." When prompted to log in, go to the "New FedEx.com Users" column and click "FedEx Ground Return Pickup." Enter the tracking ID from the shipping label and enter other information needed. On special instructions, describe exactly where in the store the pharmacy/box is being kept.

3. Maintain a copy of the completed Serialization Tracking Sheet in your files for at least 2 years (at the collector's registered location). Refer to 21 CFR § 1304.04(a).
4. Inmar will maintain your modified Form 41 noting destruction date and time on file and will provide it to you upon request.

QUICK STEPS

TO START

- 01** Install the Consumer Drug Take-Back Kiosk per DEA guidelines.
- 02** Properly tape container at bottom.
- 03** Place Serialized Inner Liner inside with top folded over container flaps.
(When inserting Serialized Inner Liner, check to ensure Serial Number on Inner Liner matches Serial Number on the shipping container.)
- 04** Place absorbent pad in bottom of Serialized Inner Liner.
- 05** Document the installation of the container on the Serialization Tracking Sheet.
- 06** Install container inside Consumer Drug Take-Back kiosk.
- 07** Lock bottom door and unlock top door to begin drug take-back collection.

TO CLOSE

- 01** Open bottom door.
- 02** Remove full container, total weight of container **may not exceed 66lbs in weight.**
- 03** Ensure the Serial Number is visible before using a zip tie to secure Serialized Inner Liner bag top.
- 04** Document the removal of the container on the Serialization Tracking Sheet.
- 05** Properly tape container at top.
- 06** Container is pre-labeled for return shipment.
- 07** Schedule pickup with FedEx.


NOTE: All direct contact with the unsealed Consumer Drug Take-Back liner must be performed by two pharmacy personnel.

HOW TO SEAL THE LINER TO PREPARE FOR SHIPPING




01

Immediately seal the Serialized Opaque Liner by gathering the top of the Liner.



02

Bend the gathered portion at the halfway point and fold the top half alongside the bottom half.



03

Repeat Step 2 - Again bend the gathered portion at the halfway point and folding the top half alongside the bottom half.



04

Cinch and fully tighten the provided Black Zip Tie around both halves of the gathered portion of the Liner to secure the top.

